

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

SEP 08 1992

O. C. D.
GENERAL OFFICE

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Hanagan Petroleum Corporation

3. Address and Telephone No.

P.O. Box 1737 Roswell New Mexico 88202 505-623-5053

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FSL 660 FWL

Sect. 1

T-26-S

R-29-E

5. Lease Designation and Serial No.

NM 86557

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Heyco Fed. #1

9. API Well No.

30-015-27044

10. Field and Pool, or Exploratory Area

Wildcat

11. County or Parish, State

Eddy New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form 1)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set 5-1/2" Cast Iron Bridge Plug at 5850' cap with 35' of cement.
- 2) Load hole with mud.
- 3) Cut 5-1/2" casing at 3885' and pulled out of hole.
- 4) Spot 30 sacks cement at 5-1/2" stub 50' in at 3960'
W.O.C. Tag plug at 3829'.
- 5) Spot 30 sacks cement at 2100'.
- 6) Spot 35 sacks cement at 8-5/8" shoe at 456'
W.O.C. Tag plug at 340'.
- 7) Spot 15 sacks cement at surface from 50' to surface. Set up P & A marker.

P&A ON 8/16/92.

Post ID-2
9-14-92
P&A

14. I hereby certify that the foregoing is true and correct

Signed

Title

Date

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any: