

Sotol Federal No. 3

Additionally Perforate and Acidize The Delaware

MIRU pulling unit. TOH with rods and pump. Install BOP.
Perforate the Delaware from 5950-74, 6110-19, 6164-82' (Total 102 holes).
Set RBP at 6287'.
Acidize perfs 6110-82 with 1350 gals 7-1/2% NEFE.
Move RBP to 6039'.
Acidize perfs 5950-74' with 1200 gals 7-1/2% NEFE.
Swab back load.
Place well on test.

MIRU pulling unit. TOH with rods and pump. Install BOP.
Set RBP at 7316'. Test RBP. Spot acid. TOH.
Perforate the Delaware from 7030-38, 7082-84, 7098-7104, 7108, 7113, and 7197-7201
(Total 32 holes).
Acidize Perfs 7030-7201 with 1400 gals 7-1/2% NEFE.
Swabbed tested.
Pulled RBP and packer.

4/27/96 Placed well back on pump.

c:\files\regulat.ory\sotol3.doc