

Sotol Federal No. 5

Additionally Perforate and Acidize The Delaware

MIRU pulling unit. TOH with rods and pump. Install BOP.

Perforate the Delaware from 4597-4606' (9', 18 holes) and from 6696-6711' (15', 30 holes).

Set RBP at $\pm 6800'$.

Acidize perfs 6696-6711 with 750 gals 7-1/2% NEFE.

Move RBP to $\pm 4700'$.

Acidize perfs 4597-4606' with 500 gals 7-1/2% NEFE.

Place well back on production.

c:\files\regulat.ory\sotol5.doc