

Recompletion Procedure - Sotol Federal No. 2

Set RBP at 7,803. Test to 3000 psi.

Spot 300 gals 7 ½ % NEFE from 7,620'-7,720'.

Perforate as follows:

7,682'-7,686' and 7,698'-7,710', 2 JSPF, 32 holes, 4" gun.

Acidize perms 7,682'-7,710' with 800 gals 7 ½ % NEFE and 48 ball sealers at 4 ½ BPM at 1700 psi avg pressure down 2 7/8" tubing.

Perforate from 7,556'-7,560'; pull RBP. Run production tubing. Place well back on production.