

8/20/98: TIH w/ mill, 4 collars, & tbg. Drlg retainer out. Stripper rubber blew out causing stud bolt on top of BOP to fall down hole. Trip tbg & recover bolt. TIH w/ tools & drill out retainer, chasing to btm. POOH w/ tbg & tools. SWI.

8/21/98: MIRU Jarrel Service. Set 7" cmt retainer on WL @ 6600'. TIH w/ tbg & sting into retainer. Establish pump in rate, follow w/ 730 sx CI "C" cmt. Wash lines, begin displacement. Continue pumping until cmt was displaced to top of retainer, ISDP 900#. POOH w/ tbg & SD over weekend.

8/26/98: Ran Schlumberger USID CBL from 6593 – 4000', no cement. TIH w/perf gun, 4 JSPF, 4 holes @ 5050'. POOH. Pmp 45 bbl 10# brine dwn csg. Caught pressure. At 700# continuing to pmp 4.5 BPM. Pmpd total 140 bbl of 10#, rec 122 bbl. SIP on slight vac. SWI.

8/26/98: Run EZ-Drill retainer on WL, set @ 5000', POOH. RIH w/tbg & sting into EZ-Drill. Press csg to 500#, set inject rate of 3.5 BPM @ 600#. Pmp 150 bbl nitrified wtr, pmp 10 bbl spacer FW. Mix 150 sx cmt & displ w/28 BW 500#. Pull out of EZ-Drill & wash up. Rev out cmt. ISDP 500#. POOH w/tbg. SDFN.