

NMOC

Wednesday, February 12, 2003

Well: Ricky #1

Field: Basin Fruitland Coal
1194-1198
1220-1224

PLUG AND ABANDON PROCEDURE.

1. MOL with cementers, hold safety meeting, blow well down and kill with water if necessary.
2. Connect cement truck to 2 7/8" casing and fill 40 sacks (47 Cu. Ft.) Class B cement, add 1/2# per sack of celloflake to first 5 sacks of cement. Pump cement until casing stands full of cement. Volumes based on 18% excess.
3. Install dry hole marker.
4. Location will not be reclaimed. Well pad will be used for Ricky #1R.