

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF 080715

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		7. UNIT AGREEMENT NAME NONE
2. NAME OF OPERATOR DYNA RAY OIL AND GAS CO., INC.		8. FARM OR LEASE NAME HILL ABRAHAM
3. ADDRESS OF OPERATOR 4101 E. Louisiana Avenue, Denver, Colorado, 80222		9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' from south line 990' from west line		10. FIELD AND POOL, OR WILDCAT SOUTH BLANCO PC
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA SEC. 24 SW4 T24N-R2W
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 7350 DF.		12. COUNTY OR PARISH RIO ARRIBA
		13. STATE NEW MEXICO

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was plugged and abandoned as follows:

1. Set 50 sack cement plug in open hole. Top of plug at 3200' inside 7" casing.
2. Cut off 7" casing at 1133'. Placed 50 sack cement plug on top of 7" casing. Pulled casing.
3. Pumped 25 sacks of cement into 10 3/4" surface casing.
4. Erected dry hole marker.



18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side