UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wel	15
	5. Lease Number
	SF-078885
. Type of Well GAS	6. If Indian, All. or Tribe Name
	7. Unit Agreement Name
. Name of Operator	•
BURLINGTON RESOURCES OIL & GAS COMPANY	Canyon Largo Unit
OIL & GAS COMPANT	8. Well Name & Number
Address & Phone No. of Operator	Canyon Largo U #225
PO Box 4289, Farmington, NM 87499 (505) 326-9700	9. API Well No. 30-039-20787
Location of Well, Footage, Sec., T, R, M	10. Field and Pool
800'FSL, 1180'FWL, Sec.3, T-25-N, R-6-W, NMPM	So Blanco Pict Clif 11. County and State Rio Arriba Co, NM
2. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE	REPORT, OTHER DATA
Type of Submission Type of Ac Notice of Intent X Abandonment	ction Change of Plans
Notice of Intent _X_ Abandonment	Change of Flans New Construction
X_ Subsequent Report Plugging Back	Non-Routine Fracturing
Casing Repair	Water Shut off
Final Abandonment Altering Casing _ Other -	Conversion to Injection
3. Describe Proposed or Completed Operations	
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fa neat cmt inside csg @ 1815-2832' to woc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 so retainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700 inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Sbradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead. WH. Found cmt @ surface. Install dry	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt "csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcium chloride cover Nacimiento interval.
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fa neat cmt inside csg @ 1815-2832' to woc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 so retainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700 inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Sbradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead.	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt "csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcium chloride cover Nacimiento interval.
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fa neat cmt inside csg @ 1815-2832' to woc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 so retainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700 inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Sbradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead. WH. Found cmt @ surface. Install dry SDON.	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt "csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcium chloride cover Nacimiento interval.
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fareat cmt inside csg @ 1815-2832' to cwoc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 scretainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700-inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Sbradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead. WH. Found cmt @ surface. Install dry SDON. 3-14-02 RD. Rig released. Well plugged and abandoned 3-13-02.	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt " csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcirc 2 bbl cmt surface. ND BOP. Cut hole marker w/5 sx Class "B" neat c
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fa neat cmt inside csg @ 1815-2832' to woc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 so retainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700 inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Sbradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead. WH. Found cmt @ surface. Install dry SDON. 3-14-02 RD. Rig released. Well plugged and abandoned 3-13-02.	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt " csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcirc 2 bbl cmt surface. ND BOP. Cut hole marker w/5 sx Class "B" neat c
3-12-02 MIRU. ND WH. NU BOP. TIH w/2 7/8" gauge CIBP, set @ 2832'. TOOH. TIH, tag top bbl wtr. PT 2 7/8" csg to 500 psi, fareat cmt inside csg @ 1815-2832' to woc. SDON. 3-13-02 (Joe Ruybalid, BLM on location). TIH, 500 psi, failed. TOOH. TIH, perf 3 so retainer, set @ 747'. TOOH. PT 2 7/8' injection. Plug #2: pump 35 sx Class outside csg below cmt retainer @ 700 inside csg above cmt retainer inside TOOH. TIH, perf 2 sqz holes @ 174'. Subradenhead w/6 bbl wtr. Plug #3: pump chloride down csg & out bradenhead. Wh. Found cmt @ surface. Install dry SDON. 3-14-02 RD. Rig released. Well plugged and abandoned 3-13-02.	o of CIBP @ 2832'. Load hole w/17 ailed. Plug #1: pump 28 sx Class "B" cover Pictured Cliffs interval. TOOH tag TOC @ 2008'. PT 2 7/8" csg to gz holes @ 800'. TOOH. TIH w/cmt " csg to 500 psi/15 min, OK. Establi "B" neat cmt w/2% calcium chloride -800'. Pump 5 sx Class "B" neat cmt csg to cover Nacimiento interval. TOOH. Establish circ down csg & out p 60 sx Class "B" neat cmt w/2% calcirc 2 bbl cmt surface. ND BOP. Cut hole marker w/5 sx Class "B" neat c