

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT - " for such proposals

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other		5. Lease Designation and Serial No. <b>SF-080658</b>
2. Name of Operator <b>AMOCO PRODUCTION COMPANY</b>		6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. <b>P.O. Box 800, Denver, Colorado 80201</b>		7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) <b>890 FSL 990 FEL Sec. 25 T 26N R 6W</b>		8. Well Name and No. <b>SAUNDERS LS #1</b>
		9. API Well No. <b>3003906284</b>
		10. Field and Pool, or Exploratory Area <b>SO BLANCO PC</b>
		11. County or Parish, State <b>RIO ARriba NEW MEXICO</b>

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent <input type="checkbox"/> Subsequent Report <input type="checkbox"/> Final Abandonment Notice	<input checked="" type="checkbox"/> Abandonment <input type="checkbox"/> Recompletion <input type="checkbox"/> Plugging Back <input type="checkbox"/> Casing Repair <input type="checkbox"/> Altering Casing <input type="checkbox"/> Other <input type="checkbox"/> Change of Plans <input type="checkbox"/> New Construction <input type="checkbox"/> Non-Routine Fracturing <input type="checkbox"/> Water Shut-Off <input type="checkbox"/> Conversion to Injection <input type="checkbox"/> Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

AMOCO INTENDS TO PLUG AND ABANDON THIS WELL PER THE ATTACHED PROCEDURE.

**RECEIVED**  
FEB 22 1994  
OIL CON. DIV.  
DIST. 3

SEE AT  
CONDITIONS OF APPROVAL

*This was in  
filing, but wasn't  
signed by Chels.,  
so made him  
a copy CS*

94 FEB 14 PM 2:40  
070 FARMINGTON, NM

RECEIVED  
BLM

14. I hereby certify that the foregoing is true and correct

Signed

*A Wayne Branam*

Title

**BUSINESS ANALYST**

Date

**02-07-1994**

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statements or representations as to any matter within its jurisdiction.

Saunders LS #1  
PXA Procedures

1. Check location for anchors. Install if necessary. Test anchors.
2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOPE.
3. POOH with 1 1/4" tbg and lay down. RIH with 2 3/8" tbg and cement retainer. Set retainer at 2825'. Test casing integrity to 500#.
4. Squeeze perfs from 2876' to 2930' with 41.756 cuft cement. Pull out of retainer and spot cement plug to 2300'. (105.21 cuft cement)
5. RIH with perf gun. Shoot squeezes holes at 2300' . RIH with cement retainer and set 50' above squeezes holes and attempt to circulate to surface through squeezes holes with 797.18 cuft cement. (est to surface) Pull out of hole and spot cement plug to 710' with 318.63 cuft cement. RIH with perf gun and shoot squeezes holes at 710' and circulate to surface through squeezes holes and displace cement to surface. ( 142.284 cuft cement.)
6. NDBOPE. Cut off casing and wellhead. Install PXA marker according to BLM or state requirements.
7. Turn over to John Schwartz for reclamation.
8. Rehabilitate location according to BLM or State requirements.

SAUNDERS LS 001  
Location - 25P- 26N- 6W  
SINGLE PC  
Orig. Completion - 8/58  
LAST FILE UPDATE - 1/94 BY CSW

NM AT 660

OJ AT 2231

KL AT 2443

FT AT 2652

PC AT 2873

PC--4SPF PERF 2876-2890 ]

2912-2930 ]

PBTD AT 2940 FT.

TOTAL DEPTH 2951 FT.

BOT OF 8.625 IN OD CSA 125  
24 LB/FT  
TOC - SURF

BOT OF 1.25 IN OD TBG AT 2910

BOT OF 5.5 IN OD CSA 2950  
15.5 LB/FT  
TOC - 2310

FILENAME:  
03906284

IN REPLY REFER TO:  
(07337)

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT  
FARMINGTON DISTRICT OFFICE  
1235 La Plata Highway  
Farmington, New Mexico 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 1 Saunders LS

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Leases."
2. Mike Flaniken with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.
3. The following modifications to your plugging program are to be made (when applicable):

Office Hours: 7:45 a.m. to 4:30 p.m.