

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT - " for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

ENERGEN RESOURCES CORPORATION

3. Address and Telephone No.

2198 Bloomfield Highway, Farmington, NM 87401

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990' FSL, 990' FEL, Sec. 20, T26N, R3W, N.M.P.M.

5. Lease Designation and Serial No.

Jic 98

6. If Indian, Allottee or Tribe Name

Jicarilla

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Jicarilla 98 3A

9. API Well No.

30-039-21288

10. Field and Pool, or exploratory Area

Gavilan PC/Blanco MV

11. County or Parish, State

Rio Arriba NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☒ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is intended to squeeze the Cliffhouse and Menefee and test the PC as follows:

1. MIRU. TOH. TIH with packer set at 5950'. Swab test Point Lookout.
2. If productive. TOH. Set RBP at 6000'. TIH with packer set 5400'. Squeeze 5500' and cap with 8 sks cement to abandon MV.
3. Drill out squeeze cement. Test casing to 500 psi. TOH.
4. TIH with tubing to 3900'. Swab test PC. TOH
5. TIH and retrieve RBP. TOH.
6. Land production tubing at 6100'. Swab in and return to production.

14. I hereby certify that the foregoing is true and correct

Signed Monica Papp Title Production Assistant Date 2/7/00

(This space for Federal or State office use)

Approved by [Signature] Title Lands and Mineral Resources Date 2/25/00

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\* See Instruction on Reverse Side