

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT -" for such proposals

5. Lease Designation and Serial No.

Jicarilla Contract 152

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA, Agreement Designation

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

ENERGEN RESOURCES CORPORATION

3. Address and Telephone No.

2198 Bloomfield Highway, Farmington, NM 87401

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1100' FNL, 790' FWL, Sec. 6, T26N, R5W, N.M.P.M.

8. Well Name and No.

Jicarilla West 9A

9. API Well No.

30-039-21979

10. Field and Pool, or exploratory Area

Otero Chacra/Blanco MV

11. County or Parish, State

Rio Arriba NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Plug Chacra
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is intended to abandon the Chacra Formation and refrac the Mesaverde as follows:

1. MIRU. Release packer and TOH.
2. TIH with RBP & packer. Set RBP at 4400'. Packer 4000'. Squeeze off Chacra with 75 sk cement. TOH. WOC.
3. TIH with bit. Drill out cement. Test casing. TOH. TIH and retrieve RBP.
4. Set CIBP at 5000'. Reperf and frac Cliffhouse from 4830-4900'.
5. TIH and clean out to 5500'. Land tubing at 5400'. Return to production.

14. I hereby certify that the foregoing is true and correct

Signed Monica Papp Title Production Assistant Date 11/15/99

(This space for Federal or State office use)

Approved by [Signature] Title PE Date 12/22/99
Conditions of approval, if any: