

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. ST-079395	
2. NAME OF OPERATOR Shelly Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME _____	
3. ADDRESS OF OPERATOR P. O. Box 730, Hobbs, New Mexico		7. UNIT AGREEMENT NAME East Dist Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1900' FWL & 1900' FWL Sec. 33 25N-10W		8. FARM OR LEASE NAME _____	
14. PERMIT NO. _____		9. WELL NO. 64	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6881' DF		10. FIELD AND POOL, OR WILDCAT Dist Lower Gallup	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 33-25N-10-W	
		12. COUNTY OR PARISH San Juan	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) Repair Casing Leak	X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) _____	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in and rig up Pulling Unit.
2. Pull rods and tubing.
3. Run DM Bridge Plug & RTTS Packer on 2 3/8"OD tubing.
4. Set Bridge Plug at 5000'.
5. Locate casing leak by pressure testing.
6. Squeeze holes in casing with 150 sacks of cement.
7. Run tubing with bit, drill out cement and test squeeze job with 1000 psi.
8. Drill out bridge plug and clean well out to PSID 5374'.
9. Re-perforate 5 1/2"OD casing 5321-5335' and 5352-5367'.
10. Run tubing and rods.
11. Return well to a producing status.

Note: Please return approved copy to the above address

RECEIVED

DEC 19 1966

GEOLOGICAL SURVEY
FARMINGTON, N. M.



18. I hereby certify that the foregoing is true and correct

SIGNED _____

TITLE _____

District Superintendent

DATE _____

December 16, 1966

(This space for Federal or State office use)

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.