

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir,
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
Central Resources, Inc.

3. Address and Telephone No.
P.O. Box 1213, Bloomfield, New Mexico 87413 (505) 682-3476

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
2553' FNL, 2325' FEL, Sec. 14, T25N, R12W

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
SF078067

6. If Indian, Allottee or Tribe Name

7. If Unit or CA. Agreement Designation

Carson Unit

Water well

8. Well Name and No.

3-14

9. API Well No.

3004505-391

10. Field and Pool, or Exploratory Area

Bisti Lower Gallup

11. County or Parish, State

San Juan, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☐ Notice of Intent

☐ Subsequent Report

☒ Final Abandonment Notice

☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

October 23-25, 2001

- A. Set a CIBP at 2672' and spot cement on top to 2672' using 28 sacks cement.
- B. Bring top of Mesa Verde plug from 1630' to 1530' inside outside 7" casing using 28 sacks cement.
- C. Set Pictured Cliffs plug from 1282' to 1182' inside and outside 7" casing using 28 sacks cement.
- D. Place the Fruitland Plug from 990' to 890' inside and outside 7" casing using 58 sacks cement.(30 outside, 2
- E. Place the surface plug from 117' to surface inside and outside the 7" casing using 55 sacks cement circulate good cement out bradenhead valve.
- G. Cut well head and install dry hole marker. Clear and remediate location.

14. I hereby certify that the foregoing is true and correct

Signed Patty Shelton

Title Production Technician

Date 02/13/01

(This space for Federal or State office use)

Approved by _____

Title _____

Date _____

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any manner within its jurisdiction.

*See Instruction on Reverse Side

R 1 15 2001

NMOC FARMINGTON COPY

5-2

OFFICE