Form 3160-5 (June 1990)

amendel

**UNITED STATES** 

DEPARTMENT OF THE INTERIO

BUREAU OF LAND MANAGEMEN

## FORM APPROVED Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No. SF 078056

## 6. If Indian, Allottee or Tribe Name

SUNDRY NOTIC	ES AND REPORT	S QN WELLS			
Do not use this form for proposals  Use "APPLICATIO	7. If Unit or CA. Agreement Designation				
SUBM	Central Bisti Unit				
1. Type of Well Oil Well G	as Well X Other	Water Injection Well	8. Well Name and No. Central Bisti Unit #WI-13		
2. Name of Operator			9. API Well No.		
Central Resources, Inc. for	30-045-055090				
3. Address and Telephone No.	10. Field and Pool, or Exploratory Area				
P.O. Box 1213, Bloomfield	Bisti Lower Gallup				
4. Location of Well (Footage, Sec., T.,	11. County or Parish, State				
660' FNL, 660' FEL, Sec. 8	San Juan, New Mexico				
12. CHECK APPROPRIATE BOX	Γ, OR OTHER DATA				
TYPE OF SUBMISSION		TYPE OF ACTI	ON		
	X Abai	ndonment	Change of Plans		
Notice of Intent Recompletion		New Construction			
	Plugging Back		Non-Routine Fracturing		
Subsequent Report	Casing Repair		Water Shut-Off		
Altering Casing		Conversion to Injection			
X Final Abandonment Notice	Othe	r	Dispose Water		
			e: Report results of multiple complet on on Well		
			Completion or Recompletion Report and Log form.)		

13. Describe Proposed or Completed Operations (Clearly state all pertinent dates, including estimated date of starting any proposed work. It well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

January 9-10th.

- A. Set a CIBP at 4692' and spot cement on top to 4479' using 30 sacks cement.
- B. Bring top of Mesa Verde plug from 1915' to 1815' inside outside 5 1/2" casing using 47 sacks cement, didn'
- C. Second attempt, bring top of Mesa Verde plug to 1759' inside outside 5 1/2" casing using 47 sacks cement.
- D. Set Pictured Cliffs plug from 1175 to 1075' inside and outside 5 1/2" casing using 17 sacks cement.
- E. Place the Fruitland Plug from 850' to 750' inside and outside 5 1/2" casing using 47 sacks cement.
- F. Pl ace the surface casing shoe plug at 400' to 300" inside and outside 5 1/2" casing using 47 sacks cement.
- G. Place the surface plug at 175' to surface inside and outside the 5 1/2" casing to surface using 150 sacks cem cover the Ojo Alamo interval.
- H. Cut well head and install dry hole marker. Clear and remediate location.

14.—I hereby certify that the foregoing is true an	d correct			<del></del>	
Signed Signed	Title Production Technician	Date	01/15/2001	59	
Patty Shelton			- ;	:.)	
(This space for Federal or State office use)			<del></del>		
Approved by	Title	Date			
Conditions of approval, if any:		<del></del>	CCEP	CCEPTED FOR RECOR	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the Little Stage Stage factitious or fraudulent statements or representations as to any manner within its jurisdiction.