


**Procedure
for
Plunger Lift Installation**

1. Recommend installation of 2 3/8" tubing. Ideally, tubing should be set low in the perforated interval.
2. Rig up wireline unit and tubing lubricator. RIH w/ wireline and set Standing Valve and Bumper Spring. RD wireline unit & lubricator.
3. Install Plunger Lift controller, Motor Valves, Catcher Lubricator, and Transducer Connections.
4. Drop plunger and adjust controller for well specific operation.
5. Thank You.

Prepared by:



Randy B. Herring
Production Engineer