

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Amoco Production Company Attn: John Hampton

3. Address and Telephone No.

P.O. Box 800 Denver, Colorado 80201

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650 FSL, 1670 FEL Sec. 18, T28N-R7W Unit "J"

5. Lease Designation and Serial No.

SF-078417

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

San Juan 28-7 Unit #248E

9. API Well No.

30-039-22364

10. Field and Pool, or Exploratory Area

Basin Dakota

11. County or Parish, State

Rio Arriba, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Bradenhead Repair
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Amoco intends to perform the attached workover procedure required to eliminate bradenhead pressure.

In addition, Amoco also requests approval to construct a temporary 15'X15'X 50' blow pit for return fluids. This pit will be reclaimed if utilized, upon completion of this operation.

RECEIVED

FEB 12 1992

OIL CON. DIV. I
DIST. 3

Please contact Cindy Burton (303) 830-5119 if you have any questions.

14. I hereby certify that the foregoing is true and correct

Signed

J. L. Hampton

Title Sr. Staff Admin. Supv.

APPROVED

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

AMOCO

FEB 11 1992

/s/ Ken Townsend
AREA MANAGER

GENERAL INSTRUCTIONS

This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special in-

structions concerning the use of this form and the number of copies to be submitted, particularly with regard to local area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

SPECIFIC INSTRUCTIONS

Item 4—If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 13—Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive

zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

NOTICE

The Privacy Act of 1974 and the regulation in 43 CFR 2.48(d) provide that you be furnished the following information in connection with information required by this application.

AUTHORITY: 30 U.S.C. 181 et. seq., 351 et. seq., 25 U.S.C. et. seq.; 43 CFR 3160.

PRINCIPAL PURPOSE — The information is to be used to evaluate, when appropriate, approve applications, and report completion of secondary well operations, on a Federal or Indian lease.

ROUTINE USES:

- (1) Evaluate the equipment and procedures used during the proposed or completed subsequent well operations.
- (2) Request and grant approval to perform those actions covered by 43 CFR 3162.3-2(2).
- (3) Analyze future applications to drill or modify operations in light of data obtained and methods used.
- (4)(5) Information from the record and/or the record will be transferred to appropriate Federal, State, local or foreign agencies, when relevant to civil, criminal or regulatory investigations or prosecutions.

EFFECT OF NOT PROVIDING INFORMATION — Filing of this notice and report and disclosure of the information is mandatory once an oil or gas well is drilled.

The Paperwork Reduction Act of 1980 (44 U.S.C. 3501, et. seq.) requires us to inform you that: This information is being collected in order to evaluate proposed and/or completed subsequent well operations on Federal or Indian oil and gas leases.

This information will be used to report subsequent operations once work is completed and when requested, to obtain approval for subsequent operations not previously authorized.

Response to this request is mandatory for the specific types of activities specified in 43 CFR Part 3160.

BURDEN HOURS STATEMENT

Public reporting burden for this form is estimated to average 25 minutes per response, including the time for reviewing instructions, gathering and maintaining data, and completing and reviewing the form. Direct comments regarding the burden estimate or any other aspect of this form to U.S. Department of the Interior, Bureau of Land Management, (Alternate) Bureau Clearance Officer, (WO-771), 18 and C Streets, N.W., Washington, D.C. 20240, and the Office of Management and Budget, Paperwork Reduction Project (1004-0135), Washington, D.C. 20503.

SJ 28-7 UNIT 248E 2175
 Location - 18J- 28N- 7W
 SINGLE DK
 Orig.Completion - 5/81
 LAST FILE UPDATE - 10/91 BY CSW

BOT OF 9.625 IN OD CSA 233
 40 LB/FT, K-55 CASING
 TOC - SURF

OJO ALAMO @ 2644
 KIRTLAND @ 2739
 FRUITLAND @ 3247
 PICTURED CLIFFS @ 3489
 MESA VERDE @ 5117
 GALLUP @ 6800

BOT OF 7 IN OD CSA 3856, 20 LB/FT
 K-55 CASING
 TOC - 3100

7790 DK
 7791 Q
 7792 Q
 7793 Q
 7794 Q
 7795 Q
 7796 Q
 7797 Q
 7798 Q
 7799 Q
 7800 Q
 7801 Q
 7802 Q
 7803 Q
 7804 Q
 7805 Q
 7806 Q
 7807 Q
 7808 Q
 7809 Q
 7810 Q
 7811 Q
 7812 Q
 7813 Q
 7814 Q
 7815 Q
 7816 Q
 7817 Q
 7818 Q
 7819 Q
 7820 Q
 7821 Q
 7822 Q
 7823 Q
 7824 Q
 7825 Q
 7826 Q
 7827 Q
 7828 Q
 7829 Q
 7830 Q
 7831 Q
 7832 Q
 7833 Q
 7834 Q
 7835 Q
 7836 Q
 7837 Q
 7838 Q
 7839 Q
 7840 Q
 7841 Q
 7842 Q
 7843 Q
 7844 Q
 7845 Q
 7846 Q
 7847 Q
 7848 Q
 7849 Q
 7850 Q
 7851 Q
 7852 Q
 7853 Q
 7854 Q
 7855 Q
 7856 Q
 7857 Q
 7858 Q
 7859 Q
 7860 Q
 7861 Q
 7862 Q
 7863 Q
 7864 Q
 7865 Q
 7866 Q
 7867 Q
 7868 Q
 7869 Q
 7870 Q
 7871 Q
 7872 Q
 7873 Q
 7874 Q
 7875 Q
 7876 Q
 7877 Q
 7878 Q
 7879 Q
 7880 Q
 7881 Q
 7882 Q
 7883 Q
 7884 Q
 7885 Q
 7886 Q
 7887 Q
 7888 Q
 7889 Q
 7890 Q
 7891 Q
 7892 Q
 7893 Q
 7894 Q
 7895 Q
 7896 Q
 7897 Q
 7898 Q
 7899 Q
 7900 Q
 7901 Q
 7902 Q
 7903 Q
 7904 Q
 7905 Q
 7906 Q
 7907 Q
 7908 Q
 7909 Q
 7910 Q
 7911 Q
 7912 Q
 7913 Q
 7914 Q
 7915 Q
 7916 Q
 7917 Q
 7918 Q
 7919 Q
 7920 Q
 7921 Q
 7922 Q
 7923 Q
 7924 Q
 7925 Q
 7926 Q
 7927 Q
 7928 Q
 7929 Q
 7930 Q
 7931 Q
 7932 Q
 7933 Q
 7934 Q
 7935 Q
 7936 Q
 7937 Q
 7938 Q
 7939 Q
 7940 Q
 7941 Q
 7942 Q
 7943 Q
 7944 Q
 7945 Q
 7946 Q
 7947 Q
 7948 Q
 7949 Q
 7950 Q
 7951 Q
 7952 Q
 7953 Q
 7954 Q
 7955 Q
 7956 Q
 7957 Q
 7958 Q
 7959 Q
 7960 Q
 7961 Q
 7962 Q
 7963 Q
 7964 Q
 7965 Q
 7966 Q
 7967 Q
 7968 Q
 7969 Q
 7970 Q
 7971 Q
 7972 Q
 7973 Q
 7974 Q
 7975 Q
 7976 Q
 7977 Q
 7978 Q
 7979 Q
 7980 Q
 7981 Q
 7982 Q
 7983 Q
 7984 Q
 7985 Q
 7986 Q
 7987 Q
 7988 Q
 7989 Q
 7990 Q
 7991 Q
 7992 Q
 7993 Q
 7994 Q
 7995 Q
 7996 Q
 7997 Q
 7998 Q
 7999 Q
 8000 Q
 8001 Q
 8002 Q
 8003 Q
 8004 Q
 8005 Q
 8006 Q
 8007 Q
 8008 Q
 8009 Q
 8010 Q
 8011 Q
 8012 Q
 8013 Q
 8014 Q
 8015 Q
 8016 Q
 8017 Q
 8018 Q
 8019 Q
 8020 Q
 8021 Q
 8022 Q
 8023 Q
 8024 Q
 8025 Q
 8026 Q
 8027 Q
 8028 Q
 8029 Q
 8030 Q
 8031 Q
 8032 Q
 8033 Q
 8034 Q
 8035 Q
 8036 Q
 8037 Q
 8038 Q
 8039 Q
 8040 Q
 8041 Q
 8042 Q
 8043 Q
 8044 Q
 8045 Q
 8046 Q
 8047 Q
 8048 Q
 8049 Q
 8050 Q
 8051 Q
 8052 Q
 8053 Q
 8054 Q
 8055 Q
 8056 Q
 8057 Q
 8058 Q
 8059 Q
 8060 Q
 8061 Q
 8062 Q
 8063 Q
 8064 Q
 8065 Q
 8066 Q
 8067 Q
 8068 Q
 8069 Q
 8070 Q
 8071 Q
 8072 Q
 8073 Q
 8074 Q
 8075 Q
 8076 Q
 8077 Q
 8078 Q
 8079 Q
 8080 Q
 8081 Q
 8082 Q
 8083 Q
 8084 Q
 8085 Q
 8086 Q
 8087 Q
 8088 Q
 8089 Q
 8090 Q
 8091 Q
 8092 Q
 8093 Q
 8094 Q
 8095 Q
 8096 Q
 8097 Q
 8098 Q
 8099 Q
 8100 Q

BOT OF 1.5 IN OD TUG AT 7951

PBTD AT 8001 FT.

TOTAL DEPTH 8008 FT.

BOT OF 4.5 IN OD CSA 8008
 10.5 LB/FT, K-55 CASING

Cathodic Protection - ?

Workover Procedure
San Juan 28-7 #248E
Sec.18-T28N-R07W
Rio Arriba County, NM

1. Contact Federal or State agency prior to starting repair work.
2. Catch gas and/or water sample off of bradenhead and casing, and have analyzed.
3. Install and/or test anchors.
4. MDRTSU. Check and record tubing, casing and bradenhead pressures.
5. Blow well down, kill well if necessary with 2% KCL.
6. Nipple down well head, nipple up and pressure test BOP's.
7. Trip in the hole and tag PBTD, check for fill, trip and tally out of hole with tubing checking condition of tubing.
8. Trip in the hole with bit and scraper to the top of the perforations. A seating nipple and standing valve may be run in order to pressure test the tubing.
9. Trip in the hole with RBP and PKR. Set RBP 50-100 ft. above perforations. Trip out of hole one joint and set PKR and pressure test RBP to 1500 psi. Release PKR and pressure test csg to 1000 psi. If no leak is found, spot sand on RBP, trip out of hole and skip step 10.
10. Trip out of hole isolating leak in casing. NOTE: Once leak is located contact Brent Miller in Denver at (303) 830-4049. Spot sand on RBP and trip out of hole with PKR.
11. Determine from well file and history if a CBL needs to be run from the top of RBP to bottom of intermediate casing shoe. If this is needed, run CBL under 1000 psi and report results to Denver.
12. Bleed off any intermediate casing pressure and check for flow, fill annulus with 2% KCL water. Nipple down BOP's and tubing head, spear casing and remove slips, nipple up BOP's.
13. Run freepoint and back off casing as deep as possible but not below the intermediate casing shoe. Trip out of hole laying down and checking condition of casing.

14. Trip in the hole with bit and scraper to top of casing back off, circulate hole clean and trip out with scraper.
15. Trip in the hole with RBP and PKR and set RBP above casing backoff, trip out of hole one joint and set PKR and pressure test RBP.
16. Release packer and trip out of hole isolating leak in casing. NOTE: IF this can not be accomplished contact Brent Miller in Denver (303) 830-4049.
17. Release PKR and spot sand on RBP and trip out of hole.
18. Run, if necessary a CBL & CCL to determine cement top on the intermediate casing.
19. Perforate casing, if necessary with 4 JSPF and circulate dye to determine cement volume. Depending on the depth of the hole and circulating pressure, a PKR or a cement retainer may be needed.
20. Mix and pump sufficient cement (class B or equivalent with two hour setting time) to circulate to surface. Shut bradenhead valve and attempt to obtain a squeeze pressure and WOC.
21. Trip in the hole with bit and scraper and drill out cement and pressure test casing. Re-squeeze leaks if casing fails pressure test.
22. Trip in the hole with retrieving head for RBP, circulate sand off of RBP and trip out of hole with plug.
23. Trip in the hole with casing and tag casing backoff. Circulate the top of the back off clean with 2% KCL water. Circulate PKR fluid to fill annulus if no additional squeeze work is required. This will be determined from the previous CBL run. Tie back onto production casing and pressure test casing.
24. Nipple down BOP's and tubing head, set slips and make cut off. Install tubing head and BOP's and pressure test.
25. Trip in the hole with retrieving head for RBP, circulate sand off of RBP with 2% KCL and trip out of hole with plug.
26. Trip in hole with a sawtooth collar and/or bailer and clean out to PBTD and trip out of hole.
27. Trip in the hole with the production string (1/2 mule shoe on bottom and a seating nipple one joint off bottom), land tubing to original depth. Nipple down BOP's, nipple up well head.

28. Swab well in and put well on production.
29. Rig down move off service unit.