

Division approved plugging program

Tamanaco Oil Corporation Pound Ranch C #14, C-14-28N-1E  
Re-entered in August 1981 by Sandi Production Inc.

Downhole equipment

13 3/8" conductor pipe at 78'  
10 3/4" surface pipe at 250'. Not cemented, was probably pulled.  
9" hole drilled to 1825'. Was not cased.

1. Clean out hole to TD
2. Set a cement plug 1825' - 1700'
3. Set a cement plug 1550' - 1450'
4. Set a cement plug 1250' - 1150'
5. Set a cement plug 600' - 500'
6. Set a cement plug 150' - 50'
7. Set top plug and erect marker with 10 sacks of cement.
8. Fill pits; clean and level location.

All plugs will be separated with mud laden fluid weighing  
at least 9 P.P.G.

All plugs will be Class A, B, or C cement with or without  
an accelerator.

*CS*