

3-CCC
2-Texaco (Denver, Farm.)
1-F

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SF-678994

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Beta Development Co.	8. Farm or Lease Name Sibyl Federal
3. Address of Operator 234 Petroleum Club Plaza, Farmington, New Mexico	9. Well No. 1
4. Location of Well UNIT LETTER C , 790 FEET FROM THE North LINE AND 1560 FEET FROM THE West LINE, SECTION 32 TOWNSHIP 27 N RANGE 11 W NMPM.	10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 6134' GR	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rig up workover unit, circulate all mud and shale out of well w/fresh water 1% Calcium Chloride, CO to T.D. Pull 1-1/2" tbg. out of well, GIN w/3-7/8" bit on 2-7/8" tbg., ream out any tight places in csg. CO to T.D. Circulate hole clean. PCN and run packer on 2-7/8" tbg. w/two-seal assembly w/perforated nipple in between seals, bull plug on bottom w/stop ring. Set packer, pull tbg. up until stop ring catches at bottom of packer. This will have bottom seal assembly in side of Model "P" packer. Pump in cement, displace w/wtr., overflush w/2 bbls., slack tbg. off until top assembly sets down on packer. Swab well in. Release rig. After well has cleaned up, re-acidize w/500 gals. 15% regular mud acid.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:
SIGNED JOHN T. HAMPTON TITLE Manager DATE December 21, 1966

APPROVED BY *Ernest* TITLE *Sup. Dist. III* DATE _____
CONDITIONS OF APPROVAL, IF ANY: