Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Tureau No. 1004-0135
Expires: March 11, 1993

5. Lease	De	signa	tion	and	Serial	No.

•		 	•
-÷	~-	 ~ ~	

SUNDRY NOTICES	SF-079232	
Do not use this form for proposals to dri	6 If Indian Alleston of Talk Manager	
Use "APPLICATION FOR	R PERMIT—" for such proposals	
. SUBMIT	7. If Unit or CA, Agreement Designation	
1. Type of Well		
Oil Gas		
Well Well Other 2. Name of Operator	<u> </u>	8. Well Name and No. Bolack C LS #5
Amoco Production Company	9. API Well No.	
3. Address and Telephone No.	30-045-06202	
P.O. Box 800 Denver, Co	10. Field and Pool, or Exploratory Area	
4. Location of Well (Footage, Sec., T., R., M., or Survey De	Blanco South (Pict. Cliffs	
1150' FSL, 1750' FEL Unit "	11. County or Parish, State	
CHECK APPROPRIATE POW	TO MINIOUTE MARKET OF THE PROPERTY OF THE PROP	San Juan, NM
2. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPO	DHI, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	4
X Notice of Intent	Abandonment	Change of Plans
	Recompletion	New Construction
Subsequent Report	Plugging Back	Non-Routine Fracturing
	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing	Conversion to Injection
•	X Other Bradenhead Repair	Dispose Water
	•	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
13. Describe Proposed or Completed Operations (Clearly state al	I pertinent details, and give pertinent dates, including estimated date of start cal depths for all markers and zones pertinent to this work.)*	ing any proposed work. If well is directionally drilled,
Place apparented towarrous with interpreted with time Active	cal deputs for all markers and zones pertinent to this work.	•
		•
Amoco intends to perform the	attached workover procedure required	to oliminata
bradenhead pressure.	accached workover procedure required	to eliminate
•		
•		
	JAM22 1902 121	
	~	
•	On con. Div	
	D187. m	
		•
		· .
Plance control Civile Peril of	2021 020 5110 15	
Frease Contact Cindy Burton (303) 830-5119 if you have any questic	ons.
14. I hereby certify that the foregoing is true and conrect		- APPROVED
() Hampton Law	A Tide Sr. Staff Admin. Supv.	1/9/97
Signed Or Federal or State office use;	Tille 522 53322 Hamiti. Bugv.	Date N 6 1992
•		1002
Approved by Conditions of approval Conditions of approval	Title	AREA MANAGER

Workover Procedure Bolack C LS #5 Sec. 30-T27N-R08W San Juan County, NM

- 15. Depending on depth of hole and circulating pressure, a packer or cement retainer may be needed.16. Mix and pump sufficient cement (Class B or equivalent, with a setting time of 2 hours) to circulate to surface. Shut bradenhead valve and attempt to walk squeeze to obtain a 1000 psi squeeze pressure. WOC.
- 17. TIH with bit and scraper and drill out cement.
 Pressure test casing. TOH with bit and scraper.
- 18. TIH with retrieving head for RBP. Circulate sand off of RBP and TOH with RBP.
- 19. TIH with sawtooth collar and/or bailer and clean out hole to PBTD, if fill was found in step 7. TOH.
- 20. TIH with production string (1/2 mule shoe on bottom and seating nipple one joint off bottom) and land tubing to original depth. NDBOP. NU wellhead.
- 21. Swab well in and put on production.
- 22. RDMOSU.

PROC1