

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau 42-14424.
LEASE DESIGNATION AND SERIAL NO.

SE-078092

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Beta Development Co.	8. FARM OR LEASE NAME Douthitt
3. ADDRESS OF OPERATOR 234 Petroleum Club Plaza, Farmington, New Mexico	9. WELL NO. 3
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 165' SSL 790' FWL	10. FIELD AND POOL, OR W. CAT Basin Dakota
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 26-27N-11W NTEPM
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6430' GR	12. COUNTY OR PARISH AND STATE San Juan New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	(Other) ☐
(NOTE: Report results of multiple completion on well Completion or Recompletion Report and Log forms.)			
17. DESCRIBE PROPOSED COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)			

Repair casing leaks w/packer and Ken-pac chemicals, as follows:

Rig up work over rig, circulate out mud, sand and shale to F.D. Circulate until hole is clean. PCH. Run Baker Model "D" production packer on wire line. Set packer just below Greenhorn section w/bump out plug to keep any water or Ken-pac material from getting below packer. Gill w/tbo. Model "L" locator and tail pipe. Spot Ken-pac above Model "D", set tail pipe down on bump out plug, run tail pipe through Model "D" and land locator seals in packer. Flush up well head, set well in and re-acidize if necessary.

18. I hereby certify that the foregoing is true and correct

SIGNED _____ TITLE Superintendent DATE July 2 1967
(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Instructions

General. This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment, data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.