

NO. OF COPIES RECEIVED	1
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
~~XXXXXX~~ **FED.** ~~XXXXXX~~

5. State Oil & Gas Lease No.

SF-078896

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Beta Development Co.	8. Farm or Lease Name Mudge Federal
3. Address of Operator 125 Petr. Club Plaza, Farmington, New Mexico 87401	9. Well No. 3
4. Location of Well UNIT LETTER K , 1850 FEET FROM THE South LINE AND 1850 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 27N RANGE 11W NMPM.	10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 6184.5' G.L.	12. County San Juan

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair well as follows:

Rig up workover rig, circulate out mud, sand and shale to T.D. Circulate until hole is clean. POH. Run production packer on wire line. Set packer just below Greenhorn section w/bump-out plug to keep any water or Kem-Pac material from getting below packer. GIH w/tbg, Model "D" locator and tail pipe. Spot Kem-Pac above Model "D", set tail pipe down on bump-out plug, run tail pipe through Model "D" and land locator seals in packer.

Flange up well head, swab well in, re-acidize if necessary.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:
D. E. BAXTER

SIGNED _____ TITLE **Superintendent** DATE **February 3, 1969**

APPROVED BY *Emory C. Clum* TITLE *Secy Dist 11* DATE **2-3-69**

CONDITIONS OF APPROVAL, IF ANY: