## UNITED STATES DEPARTMENT OF THE INTERIOR

<b>D</b> .	LEASE			
	7.40	T	046	

<u> </u>	149-	Lna-	846/	

GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT NAME
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME
1. oil gas	Jernigan
	9. WELL NO.
2. NAME OF OPERATOR	#]
Southland Royalty Company	10. FIELD OR WILDCAT NAME South Blanco Pictured Cliffs
3. ADDRESS OF OPERATOR	11. SEC., T., R., M., OR BLK. AND SURVEY OR
P.O. Drawer 570, Farmington, NM 87499 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA
below.)	Section 24, T27N, R9W
AT SURFACE: 1650' FSL & 990' FEL	12. COUNTY OR PARISH 13. STATE
AT TOP PROD. INTERVAL:	San Juan New Mexico
AT TOTAL DEPTH:	14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF	6015 DF
REQUEST FOR APPROVAL TO:  SUBSEQUENT REPORT OF THE PROPERTY OF	
FRACTURE TREAT	-0
SHOOT OR ACIDIZE	1982 BEARING
FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL PULL OR ALTER CASING	(NOTE: RD) elits Graffip compile on plane
PULL OR ALTER CASING  MULTIPLE COMPLETE	SURVEILLE DI FORM 9-330.
CHANGE ZONES $\Box$ $\Box$ $\Box$ $cfologo$	JAN 1 8 1985
ABANDON* U. SARMINGT	JAN 1 0 1985
(other)	OIL CON. DIV.
17 DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state	
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state including estimated date of starting any proposed work. If well is demeasured and true vertical depths for all markers, and zones pertinent	irectionally drilled, give substriace locations and it to this work.)*
12-6-82 - MIRU and pull 97 joints, 2037' 1" t	uhina
12-7-82 - Spot 31 sacks cement plug from 2119	' to 1975'. Spot 11 sacks cement plug
from 1850' to 1750'. Perf 2 squeez	e holes at 1170' and squeeze with 15
sacks cement to 1070'.	·
12-8-82 - Spot 11 sacks cement from 1170' to	1070'.
12-9-82 - Perf squeeze holes at 180' and sque	eze 27 sacks cement to surface behind
pipe. Spot 21 sacks cement plug fr	om 180' to surface. Cut off casing
and install dry hole marker.	
Subsurface Safety Valve: Manu. and Type	Set @ Ft.
18. I hereby certify that the top going is true and correct	
	0.3 1000
SIGNED WITH   YOUR TITLE Engineer	DATE December 21, 1982
(This space for Federal or State of	fice use)
	DATE
APPROVED BY TITLE TITLE TO APPROVAL, IF ANY:	
CONDITIONS OF APPROVAL, IF ANY:	CIVED ALLING TELES

Approved as to plugging of the well bore. Liability under bond is retained until surface restoration is completed.

AS AMENDED

JAN 16 1985

\*See Instructions on Reverse Side FARMINGTON DISTRICT DEC 2 0 1984

M. MILLENBACH ADEA MANAGER