Form 3160-5 (June 1990)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

<del></del> -	DEPONEO ON MELLO	5. Lease Designation and Serial No.
	S AND REPORTS ON WELLS	NM <b>X</b> 03380
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  Use "APPLICATION FOR PERMIT - " for such proposals		6. If Indian, Allottee or Tribe Name
		7. If Unit cr CA, Agreement Designation
1. Type of Well  Oil Well  Gas Well  Other		8. Well Name and No.
2. Name of Operator	Attention:	Florance D LS #6
Amoco Production Company	Lois Raeburn	9. API Well No.
3. Address and Telephone No.		Pictures Cliffs
P.O. Box 800, Denver, Colorado 8020	01 (303) 830-5294	10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  1590 FNL 890 FWL  900 FSt 1850FEL Sec. 19 T 27N R 8W		3004524648
		11. County or Parish, State  San Juan New Mexico
12. CHECK APPROPRIATE	BOX(s) TO INDICATE NATURE OF NOTICE,	REPORT, OR OTHER DATA
	TYPE OF ACTION	
TYPE OF SUBMISSION		
	Abandanmas	Change of Plans
Notice of Intent	Abandonment	New Construction
Notice of intent	Plugging Back	Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
	Altering Casing	Conversion to Injection
Final Abandonment Notice	Other	Dispose Water
	(Note: Recompl	eport results of multiple completion on Well Completion or etion Report and Log form. )
Well. 4 E VACOTT	R. COAL COMPLETION	
See attached procedure.		<i>.</i> '
If you have any questions please o	ontact Mike Kutas @ (303) 830-5159    DECEI	RECEIVED BLM 94 JUL 29 PM 1: 42 070 FARMINGTON, NM
	MOD JIO	. DIV.
14. I hereby certify that the foregoing is true and correct.	7 WM Title Business A	Ssistant Date07-27-1994
Signed V V V		
(This space for Federal or State office use)  Approved by	Title	APPROVEU
Conditions of approval, if any:		AUG 01 1994
Title 18 U.S.C. Section 1001, makes it a crime for any perepresentations as to any matter within its jurisdiction.	erson knowingly and willfully to make to any department or agency of the United S	States any false technique of traudulent statements

## and the second

The Harmon of Police Proper

State of

## PXA Procedures Florence D LS #6 Pictures Cliffs only

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. Blow down well. Kill if necessary with 2% KCL water. NDWH. NUBOP.
- 3. POOH with 1 1/4" tbg. RIH with 2 3/8" workstring and retainer. Set retainer at 2050'. Squeeze perfs at 2098' to 2130' with 35.404 cuft cement. Pull out of retainer.
- 4. Test casing integrity to 500#. Isolate casing leaks (if any) and report findings to Carolanne Wyett, 5578 or Mike Kutas, 5159 in Denver for further instructions.

FLORANCE D LS 006
Location — 18E— 27N— 8W
SINGLE pc
Orig.Completion — 6/56
Last File Update — 1/89 by BCB

