

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐
2. NAME OF OPERATOR
Southland Royalty Company
3. ADDRESS OF OPERATOR
P. O. Drawer 570, Farmington, NM 87499
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 990' FNL & 1650' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF ☐	☐
FRACTURE TREAT ☐	☐
SHOOT OR ACIDIZE ☐	☐
REPAIR WELL ☐	☐
PULL OR ALTER CASING ☐	☐
MULTIPLE COMPLETE ☐	☐
CHANGE ZONES ☐	☐
ABANDON* ☒	☐
(other) _____	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

SOUTHLAND ROYALTY COMPANY hereby proposes to plug and abandon the subject well in the following manner:

- 1) MIRU Service Unit.
- 2) Blow down or kill well if necessary.
- 3) POOH with 1" tubing visually inspect.
- 4) TIH with 1" tubing to 1930', spot 100 sacks (118 cu.ft.) cement plug.
- 5) Pull up hole to 1550', ^{spot 50' to 100'} ~~spot 50' - 7 sacks (8 cu.ft.)~~ Fruitland.
- 6) POOH with 1" tubing.

CONTINUED OTHER SIDE

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE PE DATE 9-28-83

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED
AS AMENDED

*See Instructions on Reverse Side

NMOCG

OCT 04 1983
R. Bonham
M. MILLENBACH
Asst. AREA MANAGER
[Signature]

5. LEASE
NMSE-02988
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Whitley "A"
9. WELL NO.
1
10. FIELD OR WILDCAT NAME
West Kutz Pictured Cliffs
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Section 17, T27N, R11W
12. COUNTY OR PARISH
San Juan
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
6163' DF

RECEIVED
(NOTE: Report results of multiple completion or zone change on Form 9-330.)
OCT-5 1983
D.V.
D.V. 9

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

- 7) Perf squeeze holes at ^{920'}~~800'~~. Squeeze 15 sacks (18 cu.ft.) leave 50' plug inside casing 50' outside.
- 8) Dump 10 sacks (11.8 cu.ft.) cement surface plug.
- 9) Install dry hole marker and rig down.
- 10) Clean location.