

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-078935

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Thompson Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

10-27N-12W

NMPM

12. COUNTY OR PARISH

San Juan

New Mexico

1. OIL ☐ GAS ☒ OTHER ☐  
WELL WELL

2. NAME OF OPERATOR

Beta Development Co.

3. ADDRESS OF OPERATOR

125 Petroleum Plaza, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

1850/N

1850/E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5909' G.R.

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☒(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

12-31-74 Rigged up work over unit for P & A work tubing loose on bottom, pull 1½" tubing out of hole, lay jt's # 111, 112 & 113 down (holes) go in hole with tubing (replaced 3 jts.) sting into Model "D" production packer, pump 50 sacks cement down tubing displace with 12 bbl's water, pick tubing up to 5480' base of Gallup, pump in 15 sacks cement displace with 10 bbl's water, pick tubing up to 4280'.

1-1-75 Shut down.

1-2-75 Pump 15 sacks cement @ 4280' (base of Point Lookout) displace with 8½ bbl's water, pick tubing up set 15 sacks cement @ 1827' (2 stage collar) lay tubing down, shot casing off 519', pump 25 sacks cement down 4½" casing, lay casing down, pump 25 sacks 195' at base of 10 3/4" casing, put 10 sacks cement in top of surface, no dry hole marker installed (U.S.G.S.).

18. I hereby certify that the foregoing is true and correct.

SIGNED

TITLE

Superintendent

DATE 1-7-75

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

RECEIVED

JAN 7 1975

U. S. GEOLOGICAL SURVEY  
FARMINGTON, N. M.

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.