GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 15 sacks or 100 feet in length, whichever is greater.
- 5. Any cement plug placed when well is not full of fluid, or when well may be taking fluid, will be touched after cement has set to verify proper location.
- 6. Hud must be placed between plugs. Minimum consistency of plugging mud must be 9.2 lbs/gal. Brine is to be utilized for mixing mud where possible.
- 7. Within 30 days after plugging work is completed, file Subsequent Report of Abandonment, Form 3160-5 (formerly 9-331), in quintuplicate with Area Manager, Bureau of Land Management, Caller Service 4104, Farmington, New Mexico 87499. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of coment plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 8. All permanently abandoned wells are to be marked with a permanent monument, on which has been stenciled or beaded the well name, well number, and well location by quarter-quarter, section, township and range. The monument is to be of steel pipe, not less than four inches in diameter, cemented permanently in the ground, and extending four feet above general ground level. The top should be closed with a screw cap, welding, or a cement plug.
- 9. After plugging work is completed:
 - Fill all pits, rat hole and cellar. 8.
 - Clean well location of all equipment, concrete bases, pipe, junk and ъ.
 - Cut or remove tie downs.
- If last well on lease, and no additional drilling is contemplated, fill tank battery pits, remove battery equipment, and clean and level battery location.
- Accomplish surface restoration as specified by the surface management agency or land owner.
- All above are rinimum requirements. The Subsequent Report of Abandonment will not be approved and the period of liability under the bond of record terminated until the lease is imspected and nurface work approved.

Please advise this office when the well location is ready for final inspection.

You are further advined that any instructions, orders or decisions issued by the Eureau of Land Management are subject to technical and procedural review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.