

Use "APPLICATION FOR PERMIT—" for such proposals.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log Form.)

12-19-69 Ran 82 jts. 1 1/4" JCW-55, 2.33 lbs., IJ tubing (2666') landed at 2675'.

DIST. 3

DEC 29 1969

GEOLOGICAL SUR

DATE 12-26-60

DATE _____

***See Instructions on Reverse Side**