(June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

CHMDDV	NOTICES	AND	REPORTS	ON	WELL	S

NMNM - 013860A Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Tribe Name 6. If Indian, Allottee of Use "APPLICATION FOR PERMIT - " for such proposals 7. If Unit or CA, Agreement Designation Type of Well 8. Well Name and No. Oil Weil Other 10 Russell LS 2. Name of Operator Attention: 9. API Well No. Lois Raeburn Amoco Production Company 3004521266 3. Address and Telephone No. 10. Field and Pool, or Exploratory Area P.O. Box 800, Denver, Colorado 80201 **Pictured Cliffs** 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 11. County or Parish, State Sec. 24 T 28N R 8W 1625FSL 990FWL San Juan **New Mexico** CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION TYPE OF SUBMISSION Abandonment Change of Plans Recompletion **New Construction** Notice of Intent Plugging Back Non-Routine Fracturing Water Shut-Off Subsequent Report Casing Repair Altering Casing Conversion to Injection Dispose Water Final Abandonment Notice (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) Amoco Production Company request permission to Plug and Abandon the above mentioned well to prevent any enviormental problems. See attached procedures. If you should have any questions please contact Stan Kolodzie @ (303) 830-5294 OIL COM. DIY. DIT. 3 11-07-1994 **Business Assistant** (This space for Federal or State office Approved by Conditions of approval, if any: Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, representations as to any matter within its jurisdiction. 110V 1 11994

FURM APPRUVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

P&A Russell LS 10 - PC Run 47 October 26, 1994

Procedure:

- 1. Move in rig. Rig Up. Nipple up blowout preventer.
- 2. Kill well. Pull tubing string.
- 3. Run work string and spot cement across PC zone to at least 2650'(150' above the top of the PC perfs - per BLM regulations). Pull tubing up out of cement. Apply 500 psi pressure to the cement column to obtain a squeeze. Allow the cement to set for 24 hours.
- 4. Pressure test cement to 1000 psi. Run in with tubing and tag cement top to be sure cement is 150' above the top perf. Set new cement if necessary.
- 5. Fill hole with plugging fluid.
- 6. Test Bradenhead for pressure. Contact Stan Kolodzie if Bradenhead flows gas or water. Last available test (9/29/92) showed no leakage. If bradenhead leaks, further squeezing will be required.
- 7. Set surface plug 100 feet of cement. Allow cement to set for 24 hours. Pressure test plug to 1000 psi.
- 8. Set P&A marker.
- 9. Remediate or rehabilitate surface location in accordance with federal regulations.

AUTHOR	RIZATIONS	ENGINEER	Stan	rle /	Kololu 1	
	PRODUCTION	ON FOREMAN				
B. The state of th	WORKOV	ER FOREMAN	# }		7	