Form 3160-5 (June 1990)

entations as to any matter within its jurisdiction

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No. **SUNDRY NOTICES AND REPORTS ON WELLS** SF-077123 Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. 6. If Indian, Allottee or Tribe Name Use "APPLICATION FOR PERMIT - " for such proposals 7. If Unit or CA, Agreement Designation 1. Type of Well Oil Well Gas Well 8. Well Name and No. Other Warren Com 2. Name of Operator Pat Archuleta 9. API Well No. AMOCO PRODUCTION COMPANY 3. Address and Telephone No. 3004524104 303-830-5217 P.O. BOX 800 DENVER, COLORADO 80201 10. Field and Pool, or Exploratory Area Fruitland 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 11, County or Parish, State Sec. 12 T 28N R 9W **UNIT P** 1120' FSL 1120' FEL New Mexico San Juan CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION TYPE OF SUBMISSION Notice of Intent New Construction Plugging Back Non-Routine Frecturing Subsequent Report Casing Repair Water Shut-Off Conversion to Injection Letter dated 1/22/97 Final Abandonment Notice Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* Amoco Production Company requests permission to plug and abandon this well per the attached procedures. If you have any questions contact Dave Smith at (303)0830-4502. Reference letter NMSF-077123 (WC) 3162.3-2 (7400).

/S/ Duane W. Spenger Approved by Conditions of approval, if any:		Title			
				Date	FEB 28 1997
14. I hereby certify that the fo	brehulita	Title	Staff Assistant	Date	02-17-1997

OH COH. DIV.

* See Instructions on Reverse Side

Warren Com #3 Orig. Comp. 1/9/80 TD = 6727', PBTD = 2780'

Page 2 of 2

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOP.
- 3. RIH and spot 100' cement plug across the Pictured Cliff at 2073' to 2173' (33 cuft cement), Fruitland at 1592' to 1692' (33 cuft cement), Ojo Alamo at 1050' to 1150' (33 cuft cement), and 290' to surface (75 cuft cement).
- 4. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
- 5. Contact FMC and ship surface equipment to yard or other location per instructions.
- 6. Turn over to John Schwartz for reclamation.
- 7. Rehabilitate location according to BLM or State requirements.