Form 3160-5 (June 1990)

representations as to any matter within its jurisdiction.

UNITED STATES

FÓRM APPROVED				
Budger Bureau No. 1004-0135				
Expires: March 31, 1993				

DEPARTM	ENT OF	THE INTERIOR
BUREAU O	LAND	MANAGEMENT

SUNDRY NOTICES AN	SF-077085	
Use "APPLICATION FOR F	r to deepen or reentry to a different reservoir. PERMIT - " for such proposals : 101 0 11 11 11 12 13 11 11 12 13 14 15 15 15 15 15 15 15	6. If Indian, Allottee or Tribe Name
	F. If Unit or CA, Agreement Designation	
1. Type of Well Oil Well Well Other		8. Well Name and No.
2. Name of Operator	Attention;	Omler "A"
Amoco Production Company	Lois Raebrun	9. API Well No.
3. Address and Telephone No.		3004512168
P.O. Box 800, Denver, Colorado 80201	(303) 830-5294	10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)	1)	Basin Dakota
000561 0005741	Sec. 25 T 28N R 10W	11. County or Parish, State
990FSL 990FWL S	25 1 2011 N 10W	San Juan New Mexico
12. CHECK APPROPRIATE BOX(S	s) TO INDICATE NATURE OF NOTICE, F	REPORT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
Notice of Intent Subsequent Report Final Abandonment Notice		Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water Dispose Mater oort results of multiple completion on Well Completion or longer and Log form.
	rtinent details, and give pertinent dates, including estimated date of startin	
See Attached Procedures	nission to Plug and Abandon the above mentioned	
If you should have any questions please c	ontact Mike Kutas @ (303) 830-5159	
		DEGETVED OLL 12 1994
		ML GOM. DIV. Dist. 3
14. I hereby certify that he foregoing is true and correct Signed	TitleBusiness Ass	sistant _{Date} 11-14-1994
(This space for Federal or State office use)		ADDDAUAG
	Tista	APPROVED
Approved by Conditions of approval, if any:	Title	DF 0 0 8 1994
Title 18 U.S.C. Section 1001, makes it a crime for any person knowi	ingly and willfully to make to any department or agency of the United Sta	tes of Palse, Newcould Colon Manuages

PXA Procedures Omler A 4 Dakota only

- 1. RIH with CIBP and set at 6245'. RIH with wireline and spot 50' of cement on top (4.475 cuft cement.)
- 2. RIH with cement retainer and set at 4550. Squeeze below retainer with 75 sx of cement. Pull out of retainer and spot 50' of cement on top. (4.475 cuft cement) Reverse off.