

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**OIL CONSERVATION DIVISION**

**DISTRICT I**  
P.O. Box 1980, Hobbs NM 88241-1980

2040 Pacheco St.  
Santa Fe, NM 87505

**DISTRICT II**  
P.O. Drawer DD, Artesia, NM 88210

**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-039-07483	
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name S. J. 29-5 Unit 009256	
8. Well No. SJ 29-5 Unit #37	
Pool name or Wildcat Blanco Mesaverde 72319	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG AND ABANDON A WELL IN A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator Phillips Petroleum Company	
3. Address of Operator 5525 Highway 64, NBU 3004, Farmington NM 87401	
4. Well Location Unit Letter <u>L</u> : <u>1800</u> Feet From The <u>South</u> Line and <u>990</u> Feet From The <u>West</u> Line	
Section <u>31</u>	Township <u>29N</u> Range <u>5W</u> NMPM Rio Arriba County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: Add pay and stimulate ☒

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU. ND WH & NU BOPs. POOH w/production tubing. Isolate existing Mesaverde perfs with bridge plug. PT casing. If casing fails test - isolate failure. Remediate with cement.

If well records indicate no cement across the Lewis Shale interval, it may be necessary to run a casing bond log (CBL). Shoot squeeze holes in casing and pump sufficient volumes of cement to cover and isolate the Lewis Shale.

Perforate and stimulate the Lewis Shale (perfs to be determined after logs are run). Retrieve bridge plug and run production tubing. Flow test the Lewis Shale.

A workover pit may be required.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Patsy Clugston TITLE Regulatory Assistant DATE 8-12-98  
TYPE OR PRINT NAME Patsy Clugston TELEPHONE NO. 505-599-3454

(This space for State Use)

ORIGINAL SIGNED BY ERNIE BUSCH

DEPUTY OIL & GAS INSPECTOR, DIST. #3

AUG 17 1998

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

100

204

1000 4-97128-0 1000 4-97128-0