

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT - " for such proposals

5. Lease Designation and Serial No.

SF-080596

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

SAN JUAN 29-6 UNIT

8. Well Name and No.

SJ 29-6 UNIT #57A

9. API Well No.

20039-21087

10. Field and Pool, or exploratory Area

BLANCO MESAVERDE

11. County or Parish, State

ARRIBA, NM

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Phillips Petroleum Company

3. Address and Telephone No.

5525 Highway 64, NBU 3004, Farmington, NM 87401

505-598-3454

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

UNIT P, 1090' FSL & 890' FEL  
SECTION 33, T29N, R6W

RECEIVED  
NOV 16 1998

OIL CON. DIV.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other ADD PAY AND STIMULATE  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*  
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

MIRU. ND WH & NU BOPs. POOH w/production tubing. Isolate existing Mesaverde perfs with bridge plug. PT casing. If casing fails test - isolate failure. Remediate with cement.

If well records indicate no cement across the Lewis Shale interval, it may be necessary to run a casing bond long (CBL). Shoot squeeze holes in casing and pump sufficient volumes of cement to cover and isolate the Lewis Shale.

Perforate and stimulate the Lewis Shale (perfs to be determined after logs are run). Retrieve bridge plug and run production tubing. Flow test the Lewis Shale.

A workover pit may be required.

14. I hereby certify that the foregoing is true and correct

Signed

*Patricia Chugan*

Title

Regulatory Assitant

Date 11-6-98

(This space for Federal or State office use)

Approved by

*/s/ Duane W. Spencer*

Title

NOV 16 1998

Conditions of approval, if any:

Date

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\* See Instruction on Reverse Side