Submit 3 Copies to Appropriate

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

District Office DISTRICT I DISTRICT II

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

OIL CONSERVATION DIVISION P.O. Box 1980, Hobbs NM 88241-1980 WELL API NO. 2040 Pacheco St. 30-039-21089 Santa Fe, NM 87505 P.O. Drawer DD, Artesia, NM 88210 Indicate Type of Lease FEE X DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410 State Oil & Gas Lease No. SUNDRY NOTICES AND REPORTS ON LA (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR P DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT 7. Lease Name or Unit Agreement Name (FORM C-101) FOR SUCH PROPOSALS(D) Type of Well: San Juan 29-6 Unit GAS WELL X 009257 OTHER 2. Name of Operator 8. Well No. Phillips Petroleum Company SJ 29-6 Unit #63A 3. Address of Operator 9. Pool name or Wildcat 5525 Highway 64, NBU 3004, Farmington NM 87401 Blanco Mesaverde 72319 4. Well Location 1080 South Feet From The 1030 Line and _ Feet From The _ Line 30 Township 6W Range Rio Arriba **NMPM** 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON **CHANGE PLANS** COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT PULL OR ALTER CASING CASING TEST AND CEMENT JOB Add pay and stimulate XOTHER: -OTHER: -12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. MIRU. ND WH & NU BOPs. POOH w/production tubing. Isolate existing Mesaverde perfs with bridge plug. PT casing. If casing fails test - isolate failure. Remediate with cement. If well records indicate no cement across the Lewis Shale interval, it may be necessary to run a casing bond log (CBL). Shoot squeeze holes in casing and pump sufficient volumes of cement to cover and isolate the Lewis Shale. Perforate and stimulate the Lewis Shale (perfs to be determined after logs are run). Retrieve bridge plug and run production tubing. Flow test the Lewis Shale. A workover pit may be required. I hereby certify that the information above is true and complete to the best of my knowledge and belief. SIGNATURE Regulatory Assistant TYPE OR PRINT NAME Patsy Clugston TELEPHONE NO. 505-599-3454 (This space for State Use) DEPUTY OIL & GAS INSPECTOR, DIST. #9 DRIGINAL SIGNED BY ERNIE BUSCH

