

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**DISTRICT I**  
P.O. Box 1980, Hobbs NM 88241-1980

**DISTRICT II**  
P.O. Drawer DD, Artesia, NM 88210

**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**

2040 Pacheco St.  
Santa Fe, NM 87505

RECEIVED  
JUN 22 1998

WELL API NO.  
30-039-21417

Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name  San Juan 29-6 Unit 009257	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER 017654		8. Well No. SJ 29-6 Unit #59A	
2. Name of Operator Phillips Petroleum Company		9. Pool name or Wildcat Blanco Mesaverde 72319	
3. Address of Operator 5525 Highway 64, NBU 3004, Farmington NM 87401			
4. Well Location Unit Letter I 1830 Feet From The South Line and 820 Feet From The East Line Section 5 Township 29N Range 6W NMPM Rio Arriba County			
10. Elevation (Show whether DF, RKB, RT, GR, etc.)			

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: Add pay and stimulate ☒

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU. ND WH & NU BOPs. POOH w/production tubing. Isolate existing Mesaverde perfs with bridge plug. PT casing. If casing fails test - isolate failure. Remediate with cement.

If well records indicate no cement across the Lewis Shale interval, it may be necessary to run a casing bond log (CBL). Shoot squeeze holes in casing and pump sufficient volumes of cement to cover and isolate the Lewis Shale.

Perforate and stimulate the Lewis Shale (perfs to be determined after logs are run). Retrieve bridge plug and run production tubing. Flow test the Lewis Shale.

A workover pit may be required.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Patsy Clugston TITLE Regulatory Assistant DATE 6-18-98  
TYPE OR PRINT NAME Patsy Clugston TELEPHONE NO. 505-599-3454

(This space for State Use)

ORIGINAL SIGNED BY ERNIE BUSCH

DEPUTY OIL & GAS INSPECTOR, DIST. #3

JUN 23 1998

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: