

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SF 0782CL-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Riddle A

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

NE/4 Sec. 1, T-29-N, R-9

N.M.P.M.

12. COUNTY OR PARISH

San Juan

13. STATE
New Mexico1. (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

El Paso Natural Gas Company

3. ADDRESS OF OPERATOR

Box 990, Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1650'N, 990'E, Sec. 1, T-29-N, R-9-W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6410' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Case & Cement Mesa Verde

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*In order to increase production it is planned to workover and restimulate this well in the
following manner:

Pull tubing, set a drillable bridge plug near the bottom of the 6 5/8" casing and pressure
test to 1000 psi.
If tubing is stuck, cut off tubing approximately 100' below the 6 5/8" casing shoe, set
a drillable cement retainer near the bottom of the 6 5/8" casing, squeeze the open hole
with approximately 200 sacks of cement.
Pressure test the 6 5/8" casing with 1000 psi.
Isolate and squeeze cement any leaks. If leaks occur between 1900' and 3050' no block
squeeze of the 6 5/8" annulus is planned.
If there are no leaks, perforate 2 squeeze holes at approximately 2075' and block squeeze
the 6 5/8" annulus with approximately 100 sacks of cement.
Clean out or sidetrack and redrill to approximately 5450'.
Run a full string of 4 1/2" production casing and sufficient cement to tie into the 6 5/8"
casing shoe.
Selectively perforate and sand-water frac the Mesa Verde formation.

18. I hereby certify that the foregoing is true and correct

SIGNED

Original signed by
Carl E. Matthews

TITLE

Petroleum Engineer

OIL CON. COM.
DIST. 3

DATE 6-30-67

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

*See Instructions on Reverse Side

RECEIVED

JUN 30 1967

U. S. GEOLOGICAL SURVEY
FARMINGTON, N.M.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office. Consult local

local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office. Consult local

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.