

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug a well or to abandon a reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. NM 04139	
2. NAME OF OPERATOR El Paso Natural Gas Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR Box 920, Farmington, New Mexico 87401		7. UNIT AGREEMENT NAME San Juan 30-6 Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) 990'N, 990'E		8. FARM OR LEASE NAME San Juan 30-6 Unit	
14. PERMIT NO.		9. WELL NO. 4 (P&A)	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5580' GL		10. FIELD AND POOL, OR WILDCAT Blanco Mesa Verde	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 35, T-30-N, R-9-W	
		12. COUNTY OR PARISH N. M. P. M.	
		13. STATE Rio Arriba New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Due to non-production it is planned to plug and abandon this well as follows:

[On 1-13-67 this well was temporarily abandoned in the following manner:
Tubing was cut off at 5520' and salvaged. A cement retainer was set at 5290' and the open hole was squeezed w/250 sacks of cement. Another retainer was set at 2050' and the 7" casing was squeezed w/150 sacks of cement. (Corrosion holes in 7" between 2233' and 2530')]

Procedure to Plug and Abandon:

Determine free point of 7" and shoot off at free point. Spot a 30 sack cement plug down freed casing on stub.

If free point indicates it is unfeasible to pull 7", pump 75 sacks of Class "A" cement down the bradenhead.

Spot a 15 sack cement plug at the surface.

NOTE: Ojo Alamo was protected from contamination during primary cement job.

Install a 4' x 4" P & A marker and clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED Original Signed J. H. Wood TITLE Petroleum Engineer DATE 7-28-70

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963--O-685229

847-485

