

Douglas Kenaston
Masden - Selby #2
1000/N; 885/E
A-28-29N-11W
San Juan County

5. Presumed downhole equipment.

8 5/8" casing set at 100' with 75 sacks.
5 1/2" casing set at 1571' with 100 sacks
Total Depth 1623'.

6. Commission - approved plugging program.

Set a 35 sack cement plug from 1620 feet. Tag cement top after six hours. Cut and pull 5 1/2" casing from below 500' or perforate four holes in casing at 500' and cement inside and outside of 5 1/2" casing from 500' to 400'. Cement from 200' to 100' inside and outside of 5 1/2" casing or in open hole if casing is pulled.

Stabilize 5 1/2" casing at surface, if any, remove all junk, and level location.

