

8-16-74 made trip to Farmington after tools. rigged up and changing mill started milling at 4:30 p.m. milled until 7:00 p.m. cut 8 in.
8-17-74 cut 4 in. from 9:00 a.m. to 5:30 p.m. poor cutting circulation. AAA fishing tool people thought swedge was turning ran pipe to pull. could not pull swedge they left two change overs in hole on top of the swedge tried for $\frac{1}{2}$ day to get them out would not unscrew.

8-19-74
round trip drill pipe changed mills. milled 18 in pulled drill pipe
8-20-74
ran new mill milling on swedge pulled drill pipe out.

8-21-74
ran 2 3/8 tub. screwed on to subs and pulled out swedge.
ran packer on tubing down to 372 ft. packer would not go. pulled back out.

8-22-74

✓ had packer milled down at Ransom machine shop.
ran packer would not go

8-23-74

rigged up cable tools with drilling bitt to straighten pipe would not go.

8-34-74

decided to build packer that would go through 4 1/4 used giberson swab cup tried to buy 5 1/2 swab cup none in town

9-3-74 broke down drilling tools rigged up tubing tools worked on truck and water pump.

9-4-74

tallied and ran tub swabed well.

9-5-74-

G-6-74 swabbing water hauled drill pipe to Farmington.
swabbing water hauling drill pipe to so side rd Jess Dean

9-7-74

swabbing water

9-9-74

put water dye in cs to test packer did not hold started out with tub. hung up at bad place 6 ft from top went to Farmington for acid put acid in hole pulled tubing and fisher plastic pipe

9-10-74

fished plastic pipe went to bottom of well. with tools
had 4/7/8 rubber made from 2/3/8 stripper rubber

9-11-74

rigged up tub tools waiting on rubber

9-12-74

ran tubing in hole had to pull down through tight places
with winch line shoved water out tub all the way down

9-13-74

finished running tub bridged packer with pea gravel magagel
and 3 sk reg no2 cement;

9-16-74

Swabed well dry let set over night. put 20 gal 15% hcl acid

9-17-74

swabed well less than 1 gal of water.

shut well in. tore down rig to move to davie well.

