Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

BUREAU OF LAND	MANAGEMENT	
CLINDRY NOTICES AND	REPORTS ON WELLS	5. Lease Designation and Serial No.
SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT - " for such proposals		SF-077092B
		6. If Indian, Allottee or Tribe Name
		7. If Unit or CA, Agreement Designation
'. Type of Well		
Oil Ges Other		8. Well Name and No.
Name of Operator	Attention:	Lackey C LS 1
Amoco Production Company	Patty Haefele	
J. Address and Telephone No.	(303) 830-4988	3004508595
P.O. Box 800, Denver, Coloredo 80201		Blanco Mesaverde
4. Location of Well [Footage, Sec., T., R., M., or Survey Description]		11. County or Parish, State
990' FNL 1190' FEL Sec	. 11 T 29N R 10W Unit A	
		San Juan New Mexico
12. CHECK APPROPRIATE BOX(s)	TO INDICATE NATURE OF NOTICE,	REPORT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
	N	~~
NZI	Abandonment	Change of Plans
Notice of Intent	Recompletion Plugging Back	New Construction Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
Sacrogodii iisperi	Altering Casing	Conversion to Injection
Final Abandonment Notice	Other	Dispose Water
İ	(Note: R Recompl	eport results of multiple completion on Well Completion or letion Report and Log form.)
If you have any questions, please contact Pa	OIL COXI.	Simple Si
14. I hereby certify that the foregoing is true and correct Signed Patty Halfele (This space for Federal or State office use)	Title Business A	04.05.4004
Approved by Title Title		APPROVED
		JAN 1 ~ 1995
Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly representations as to any matter within its jurisdiction.	y and willfully to make to any department or agency of the United	DISTRICT WANAGED
	• See Institution on Reverse Side	

PXA Procedures Lackey C LS #1

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. NDWH. NUBOP.
- 3. RIH with tbg and spot 100' cement plug at 2300' with 32.22 cuft cement. RIH with perf gun and shoot squeeze holes at 2050'. RIH with cement retainer and set 50' above squeeze holes and attempt to circulate to surface with 308.12 cuft cement. Pull out of retainer and fill hole to surface with 451.08 cuft cement.
- 4. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
- 5. Turn over to John Schwartz for reclamation.
- 6. Rehabilitate location according to BLM or State requirements.

