

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name Sammons
3. Address of Operator P.O. Drawer 570, Farmington, New Mexico 87401	9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> <u>1970</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>30N</u> RANGE <u>12W</u> NMPM.	10. Field and Pool, or Wildcat Fulcher Kutz P.C.
11. Elevation (Show whether DF, RT, GR, etc.) 5423'	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: Amended Report SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) MIRU
- 2) POOH with 1" tubing. PU 2-3/8" workstring.
- 3) Spot 17 sacks of cement from 1605' to 1445'.
- 4) Determine free point of 5-1/2" casing and shoot off.
- 5) Spot 21 sacks of cement on top of cut off joint.
- 6) Spot 39 sacks of cement from 1320'-1100' to cover Fruitland, Farmington and Ojo Alamo formations.
- 7) Spot 80 sacks of cement at 80' and circulate to the surface.
- 8) Cut off surface and production casing 4' below surface.
- 9) Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. E. Zeller TITLE District Engineer DATE October 8, 1982

Original Signed by FRANK J. CHAVEZ

APPROVED BY _____ TITLE _____ DATE OCT 12 1982

CONDITIONS OF APPROVAL, IF ANY: