

If leak depth is 11' from sig

If leak 15'

Try to establish circulation.
If cannot, use procedure for low
leak.

Pump cement, 50 sn. in.
Squeeze.

Pump cement, amount to be deter-
mined when leak depth established.
Circulate in annulus.

- 5. Displace below cementer.
POH. Toward end of job, pause after every barrel to allow
cement to set. RTH and drill out to BP. Pressure test to
verify that leak is plugged. Drill out to PBTD. Rerun
tubing with packer. Set packer @6450' and swab well on.