proces

(SUBMIT IN TRIPLICATE)

Budget Bureau No. 42-R358.4. Approval expires 12-31-60.	
Land Office Santa Fe	
078139	
Unit Elliott Gas Unit	#C#

x

UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

	s	SUBSEQUENT REPORT OF WATER SHUT-OFF
OTICE OF INTENTION TO CHANGE PLAN	ıss	SUBSEQUENT REPORT OF SHOOTING OR ACIDIZING
OTICE OF INTENTION TO TEST WATER		SUBSEQUENT REPORT OF ALTERING CASING
OTICE OF INTENTION TO RE-DRILL OR	REPAIR WELL S	SUBSEQUENT REPORT OF RE-DRILLING OR REPAIR.
OTICE OF INTENTION TO SHOOT OR AC		SUBSEQUENT REPORT OF ABANDONMENT
IOTICE OF INTENTION TO PULL OR ALTI IOTICE OF INTENTION TO ABANDON WEI		SUPPLEMENTARY WELL HISTORY
OTICE OF INTENTION TO ABANDON WE		
(INDICATE A		RE OF REPORT, NOTICE, OR OTHER DATA)
lliott Cas Unit "C"	Fa	rmington, New Mexico October 11
ell No1 is located	1650 ft. from.	line and 1750 ft. from $\begin{bmatrix} E \\ \bullet \bullet \bullet \end{bmatrix}$ line of sec. 9
7/4 of Section 9 (1/2 Sec. and Sec. No.)	()	N.M.P.E.
Manco-Masaverde	San Juan	
(Field)	(County or Subdi-	
	ing points, and all other im	
e propose to workover. Move in any rig up of Clean out hole with Run 5" liner to tot.	the above well a workover rig. gas to total depal depth and ceme	ns follows: oth, or whipstock hole if necessary. outh.
e propose to workover. Move in any rig up of Clean out hole with Run 5" liner to tot.	the above well a workover rig. gas to total depal depth and ceme	oth, or whipstock hole if necessary. Into the sones.
We propose to workover 1. Move in any rig up of 2. Clean out hole with 3. Run 5* liner to tot 4. Dwill out cement are	the above well a workover rig. gas to total depal depth and ceme	oth, or whipstock hole if necessary. Into the sones.
We propose to workover. Move in and rig up of Clean out hole with B. Run 5" liner to tot. Drill out cement and Stimulate with sand	the above well a workover rig. gas to total dep al depth and cemed perforate selectivater frac.	ne follows: Oth, or whipstock hole if necessary. Other somes.
We propose to workover 1. Move in any play up of 2. Clean out hole with 3. Run 5* liner to tot. 4. Drill out cement and 5. Stimulate with sand	the above well a workover rig. gas to total dep al depth and cemed perforate selectivater frac.	as follows: Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary.
to propose to workover 1. Move in any rig up 2. Clean out hole with 3. Run 5" liner to tot. 4. Drill out cement and 5. Stimulate with sand I understand that this plan of work me company Pan American Pe	the above well a workover rig. gas to total dep al depth and cemed perforate selective approval in writing troleum Corporati	as follows: Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary. Oth, or whipstock hole if necessary.
Nove in archizupe. Clean out hole with the Prill out cement and the Stimulate with sand tunderstand that this plan of work members of the Prill out cement and the prill out cement and the sand that this plan of work members of the plan of	the above well a workover rig. gas to total dep al depth and cemed perforate selective approval in writing troleum Corporati	as follows: Oth, or whipstock hole if necessary. Oth some seary. Oth some seary. Oth some seary. Oth some seary.