(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

ABANDON*

CHANGE PLANS

SHOOT OR ACIDIZE

REPAIR WELL

Due to non-production it is planned to plug and abandon this well in the following manner:

SHOOTING OR ACIDIZING

Spot a 50 sk. cement plug over the perforations from 1915' to 2244', to cover to approximately 1600' which will cover the Ojo Alamo inside the casing. (The original cement job covered the Ojo Alamo outside the casing.)

Determine the free point by stretch of the 4 1/2" casing and shoot off. cement plug on top of the casing stub. Pull casing. Spot a 25 sk. cement plug at the base of the surface casing.

Place a 15 sks. cement plug at the surface with a 4' X 4" Plug & Abandon marker OIL COM CO Clean up location. DIST. 3 THE

to y be the state of the depending is true and correct					
SIGNEDSIGNED	TITLE	Petroleum Engineer	DATE Dece	ember 20, 19	? 71
(This space for Federal or State office use)					
APPROVED BY	TITLE		DATE		
CONDITIONS OF APPROVAL, IF ANY:			** * * * *		