

|                        |  |
|------------------------|--|
| NO. OF COPIES RECEIVED |  |
| DISTRIBUTION           |  |
| SANTA FE               |  |
| FILE                   |  |
| U.S.G.S.               |  |
| LAND OFFICE            |  |
| OPERATOR               |  |

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

|  |
|--|
| 5a. Indicate Type of Lease   |
| State <input type="checkbox"/> Fee <input checked="" type="checkbox"/> |
| 5. State Oil & Gas Lease No.   |

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

|   |  |
|---|--|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-<br>2. Name of Operator<br>El Paso Natural Gas Company<br>3. Address of Operator<br>P.O. Box 4289, Farmington, New Mexico 87499<br>4. Location of Well<br>UNIT LETTER L, 1460' FEET FROM THE South LINE AND 990' FEET FROM THE West LINE, SECTION 23 TOWNSHIP 30N RANGE 11W NMPM.<br>15. Elevation (Show whether DF, RT, GR, etc.)<br>5904 GL | 7. Unit Agreement Name<br>8. Farm or Lease Name<br>Hartman<br>9. Well No.<br>#3<br>10. Field and Pool, or Wildcat<br>Aztec Pictured Cliffs<br>12. County<br>San Juan |
|---|--|

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

|  |  |
|--|--|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/>   | CHANGE PLANS <input type="checkbox"/>                |
| PULL OR ALTER CASING <input type="checkbox"/>  | OTHER <input type="checkbox"/>                       |

### SUBSEQUENT REPORT OF:

|  |   |
|--|---|
| REMEDIAL WORK <input type="checkbox"/>               | ALTERING CASING <input type="checkbox"/>      |
| COMMENCE DRILLING OPNS. <input type="checkbox"/>     | PLUG AND ABANDONMENT <input type="checkbox"/> |
| CASING TEST AND CEMENT JOBS <input type="checkbox"/> | OTHER <input type="checkbox"/>                |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

## Plug and Abandonment Procedure

MOL and RU. Install BOP and kill well if necessary. Trip in hole with 1 1/4" work string to TD. Spot a 45 sx cement plug (50 cu. ft.) from TD to 900'. Trip out of hole and lay down tubing.

RU wireline and trip in to shoot 2 squeeze holes at 185'.

Pump 50 sx of cement (55 cu. ft.) through casing into annular space to surface, leaving 2 7/8" full of cement.

Cut off BH, set dry hole marker, RD.

MAY 02 1985  
OIL CON. DIV.  
DIST. 3

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Loren W. Fethergill TITLE Production Engineer DATE May 2, 1985

APPROVED BY E. Bunch TITLE \_\_\_\_\_ DATE 5-8-85

CONDITIONS OF APPROVAL, IF ANY: