5. LEASE

NM 28760

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

Liability under bond is retained until surface restoration is completed.

AND DEDODE ON WELLS	
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT NAME
Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.)	
	Little Federal
1. oil gas XX other well other	9. WELL NO.
2. NAME OF OPERATOR  E P X	#6  10. FIELD OR WILDCAT NAME  1. Fruitland
3 ADDRESS OF OPERATOR	Undesignated Fruitland
D.O. Roy 289 Farmington, New Mexico 87401	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	Sec. 12 T-30-N, R-14-W
below.) AT SURFACE: 1850' FSL 790 FWL	12. COUNTY OR PARISH 13. STATE
AT TOP PROD. INTERVAL:	San Juan N.M.
AT TOTAL DEPTH:	14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	30-045-22379
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)
	5961' DF
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	Marine Company
TEST WATER SHUT-OFF	
SHOOT OR ACIDIZE	
REPAIR WELL	(NOTE: Report results of multiple completion or zone
PULL OR ALTER CASING	change on Form 9-330.).
MULTIPLE COMPLETE CHANGE ZONES	
ABANDON*	Addison to the second of the s
(other)	<b>D</b> (5), 5
~	any plugged the well in the
cement into perforations.	(-(.)' from 1566' to 1150'. Squeezed
following manner.  Tagged Sand at 15  1). Spotted 30 sx cement plug cement into perforations.  2). Spotted 25 sx cement plug 3). Spotted a 10 sx surface plug 3). Spotted a 10 sx surface plug 3).	from 1566' to 1150'. Squeezed  from 950' to 650'.  lug and installed a P & A marker.  Set @Ft.
following manner.  Tagged Sand at 15  1). Spotted 30 sx cement plug cement into perforations.  2). Spotted 25 sx cement plug 3). Spotted a 10 sx surface plug 3). Spotted a 10 sx surface plug 3	from 1566' to 1150'. Squeezed  from 950' to 650'.  lug and installed a P & A marker.  Set @Ft.
following manner.  Tagged Soud at 15  1). Spotted 30 sx cement plug cement into perforations. 2). Spotted 25 sx cement plug 3). Spotted a 10 sx surface plug 3). Spotted a 10 sx surface plug 3 synthesis and synthe	from 1566' to 1150'. Squeezed  from 950' to 650'.  lug and installed a P & A marker.  Set @Ft.
following manner.  Tagged Soul at 15  1). Spotted 30 sx cement plug cement into perforations. 2). Spotted 25 sx cement plug 3). Spotted a 10 sx surface plug 3). Spotted a 10 sx surface plug 3. Spotted 3.	from 1566' to 1150'. Squeezed  from 950' to 650'.  lug and installed a P & A marker.  Set @Ft.
Subsurface Safety Valve: Manu. and Type  1). Spotted 30 sx cement plug cement into perforations. 2). Spotted 25 sx cement plug 3). Spotted a 10 sx surface plug 4. Spotted 4. Sp	from 1566' to 1150'. Squeezed  from 950' to 650'. lug and installed a P & A marker.  Set @Ft.  reffice use)