

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

<p>1. Type of Well GAS</p> <hr/> <p>2. Name of Operator BURLINGTON RESOURCES OIL & GAS COMPANY</p> <hr/> <p>3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700</p> <hr/> <p>4. Location of Well, Footage, Sec., T, R, M 1420' FNL 810' FWL, Sec.6, T-31-N, R-9-W, NMMPM</p>	<p>5. Lease Number SF-078509</p> <p>6. If Indian, All. or Tribe Name</p> <p>7. Unit Agreement Name San Juan 32-9 Unit</p> <p>8. Well Name & Number San Juan 32-9 U#33A</p> <p>9. API Well No. 30-045-23312</p> <p>10. Field and Pool Blanco Mesaverde</p> <p>11. County and State San Juan Co, NM</p>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other -	

13. Describe Proposed or Completed Operations

It is intended to install a pump in the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed *[Signature]* (MEL5) Title Regulatory Administrator Date 2/9/99
TLW

(This space for Federal or State Office use)

APPROVED BY *[Signature]* Title Team Lead, Petroleum Management Date 2/9/99

CONDITION OF APPROVAL, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

San Juan 32-9 Unit #33A
Mesaverde
1420' FNL, 810' FWL
Unit F, Section 6, T-31-N, R-9-W
Latitude / Longitude: 36° 55.8105' / 107° 49.4302'
DPNO: 6988301
Rod Pump Installation Procedure

1. Install used C-160 pumping unit.
2. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Prior to moving in rig, make one-call and then verify rig anchors and dig pit.
3. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
4. Mesaverde, 2-3/8", 4.7# J-55 tubing is set at 6120'. Broach tubing and set tubing plug in tubing at 6069'. Fill tubing with half of its volume of 2% KCL to insure the tubing plug will be held in place. Release donut; pick up additional joints of tubing and tag bottom. (Record depth). TOOH with tubing. PBTD should be at $\pm 6186'$. Visually inspect tubing for corrosion and replace any bad joints. Remove any unnecessary equipment (i.e. Tbg stop, bumper spring, etc.). Check tubing for scale build up and notify Operations Engineer.
5. PU and TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below perforations, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
6. Rabbit all tubing prior to TIH. TIH with one joint of 2-3/8" 4.7# tubing, 4' perforated sub, in-line check, 1.78" seating nipple, and then remaining 2-3/8" tubing. Replace any bad joints.
7. Land tubing at $\pm 6170'$. **NOTE: If excessive fill is encountered, discuss this landing depth with Operations Engineer.** Pump off check valve. ND BOP and NU WH.
8. If fill was encountered, contact Operations Engineer to discuss possibility of running a sand screen on the pump. PU and TIH with 2" x 1.25" x 10' x 14' RHAC-Z insert pump, from Energy Pump & Supply, 1 1-1/4" sinker bar (5/8" pin with 3/4" crossover), 3/4" Grade D rods with spray-metal couplings to 2865', and molded paraffin scrapers to surface. Test pump action and hang rods on pumping unit. RD and MOL. Return well to production.

Recommended: M.E. Lutey
Operations Engineer

Approved: Bruce W. Boyer 1-26-99
Drilling Superintendent

Operations Engineer: Mary Ellen Lutey
Office - (599-4052)
Home - (325-9387)
Pager - (324-2671)

Pump and Rods: Energy Pump & Supply
Leo Noyes
Office - (564-2874)