

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☒ other ☐
2. NAME OF OPERATOR
Southland Royalty Company
3. ADDRESS OF OPERATOR
P.O. Drawer 570, Farmington, NM 87401
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: *1450' FNL & 1300' FWL*
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:


16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) *X See Below*

SUBSEQUENT REPORT OF:

- ☐
☐
☐
☐
☐
☐
☐
☐
☐
☐



(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

SOUTHLAND ROYALTY COMPANY proposes to amend plugging program as follows to allow possible future re-entry as water disposal well:

- 1) Spot 25 sacks of Class "B" cement from 4416'. Squeeze 10 sacks into perforations.*
- 2) Spot 35 sacks of Class "B" cement from 2250' (to cover liner top and top of Pictured Cliffs at 2095').*
- 3) Shoot squeeze holes (4 spaced 90 deg. apart) at 550'.*
- 4) Open bradenhead valve, establish circulation to surface.*


Subsurface Safety Valve: Manu. and Type ****CONTINUED OTHER SIDE**** Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct


SIGNED *R. E. Fielder* TITLE *Dist. Engineer* DATE *August 20, 1982*

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL **AS AMENDED**



*See Instructions on Reverse Side



Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

GPO : 1976 O - 214-149

- 5) Cement through squeeze holes with 80 sacks of Class "B". Displace cement to 500' inside 7" casing. (Volume + 10% excess to bring cement around backside to 182'.)
- 6) Spot ^{3"}~~20~~ sacks of Class "B" cement plug from 282' to ~~182'~~ ^{Surface} inside 7" casing.
- 7) Cut off ~~wellhead~~ ^{7 5/8" Csg}, install 4" dry hole marker on 7" casing stub ~~with 10' cement plug on inside and outside of 7" casing.~~