Submit 3 Copies to Appropriate District Office	State of New Mo Energy, Minerals and Natural Ro	esources Department	Form C-100 Revised 1-1-85)
OIL CONSERVATION DIVISION P.O. Box 2088		88	WELL API NO.	
DISTRICT II P.O. Drawer DD, Artesia, NM 88210 DISTRICT III	Santa Fe, New Mexico 87504-2088		5. Indicate Type of Lesse STATE FE	E 🗵
1000 Rio Branca Rd., Aziec, NM 87410		¥.	6. State Oil & Gas Lesse No.	
(DO NOT USE THIS FORM FOR PRO DIFFERENT RESER (FORM C	CES AND REPORTS ON WEL POSALS TO DRILL OR TO DEEPEN RVOIR. USE "APPLICATION FOR PEI 101) FOR SUCH PROPOSALS.)	OR PLUG BACK TO A	7. Lucae Nome or Unit Agreement Name	
I. Type of Well: OR. GAS WELL X	OTHER		Mobil	
2. Name of Operator Joel B. Burr, Jr.			8. Well No. #1	
Address of Operator P.O. Box 50, Farmin	ngton, N.M. 87499		9. Pool name or Wildcat Flucher Kutz	
Well Location M 54	Feet From The South		Feet From The West	Line
Section 21	Towaship 30N Ra	12W	MPM San Juan	County
	57	04 GR		
n. Check A NOTICE OF INT	Appropriate Box to Indicate In ENTION TO:	_	port, or Other Data SEQUENT REPORT OF:	
ERFORM REMEDIAL WORK	PLUG AND ABANDON 📋	REMEDIAL WORK	ALTERING CASING	
EMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING	OPNS. PLUG AND ABANDONM	ENT EX


12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug as per the attached procedure

RECEIVE DANS 41992 OIL CON. DIV. DIST. 3

hereby cartify that the information above in true and complete to the best of my knowledge and balled. TITLE	1/22/92
TYPE CRIPTINAME Joel B. Burr, Jr.	TELEPHONE NO.

PULL OR ALTER CASING



December 11, 1991

Mobil #1 Well Flug & Abandonment Procedure M. 540' FSL, 765' FWL Sec. 21, TSON, R12W San Juan County, NM

Proposed Procedure:

- 1. Move cementing truck on location; blow well down.
- 2. ND wellhead and install cementing head.
- 3. Establish pump rate into perforations.
- 4. Pump Plug #1 from 1806' to surface with 50 sxs Class B neat cement.
- 4. Shut In well and WOC overnight.
- 5. Tag cement in 2-7/8" casing and fill to surface if necessary.
- 6. Cut off 7" and 2-7/8" casings below ground level and install P&A marker.
- 7. Remove fence, fill in pits and reclaim location.

