

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT..." for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. 14-20-604-89
2. NAME OF OPERATOR PAK AMERICAN PETROLEUM CORPORATION		6. IF INDIAN, ALLOTTEE OR TRIBE NAME Ute Mountain Tribal
3. ADDRESS OF OPERATOR P. O. Box 480, Farmington, New Mexico		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1705 FSL and 1980 FEL		8. FARM OR LEASE NAME Ute Mountain Tribal "A"
14. PERMIT NO.		9. WELL NO. 4
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5493 (FDB)		10. FIELD AND POOL, OR WILDCAT Verde Gallup
		11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA NW/4 SE/4 Section 33, T-21-N, R-15-W
		12. COUNTY OR PARISH San Juan
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

As a result of declining production we plugged and abandoned the above well on June 19, 1965 as follows:

1. Moved in pulling unit and pulled rods and tubing.
2. Re-ran tubing and recovered 4-1/2" slotted liner set 2917 to 3096.
3. Pumped 50 sacks cement down 5-1/2" casing with cementing plug and cement went below casing seat. Waited on cement and pumped 30 sacks additional cement to top 2800'.
4. Pumped 25 sacks cement down 5-1/2" - 8-5/8" casing annulus.
5. Removed wellhead and surface equipment.
6. Spotted 5 sack cement plug from surface to 40' and erected abandonment marker.
7. Cleaned up location and returned ground to original contours.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE July 15, 1965

(This space for Federal or State office use)

APPROVED

AUG 6 1965

JERRY W. LONG
DISTRICT ENGINEER

*See Instructions on Reverse Side

DURANGO, COLO.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1983-O-685229

807-831

