

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TWO COPIES  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.  
**Ute Mtn. Tribal Contract**  
**14-20-004-82**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
**Ute Mtn. Tribe of Indians**

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
**Ute-Indian**

9. WELL NO.  
**9-E**

10. FIELD AND POOL, OR WILDCAT  
**Verde Gallup**

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
**20-31N-1W N.M. PM**

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
**Empire State Oil Company**

3. ADDRESS OF OPERATOR  
**Box 871 Thermopolis, Wyoming**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

**660' FSL & 1920' FWL Sec. 20-T31N-R14W**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

**5596 GR**

12. COUNTY OR PARISH  
**San Juan**

13. STATE  
**New Mexico**

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☒

(NOTE: Report results of multiple completion or Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The above well was plugged and abandoned as follows:

1. Set bottom plug - 11 sacks cement - across open hole section and up into 4-1/2" casing to 3150'.
2. Shot off and pulled 4-1/2" casing at lowest free point at 1625'.
3. Filled 4-1/2" casing with mud.
4. Set 23 sack cement plug across casing stub from 1600-1700'.
5. Set 12 sack cement plug across bottom of surface casing 75'-125'.
6. Set 10 sack cement plug in top of surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned on 1-17-67.



18. I hereby certify that the foregoing is true and correct

SIGNED Thomas E. Fenno

TITLE Engineer

DATE 2-22-67

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

\*See Instructions on Reverse Side

APPROVED

MAR 28 1967

E. A. SCHMIDT  
ACTING DISTRICT ENGINEER

*St*